



## Simple **ADAPTED MUSIC PLAYER**

*Adapted Music Player* is the answer for any music lover. By connecting up to 4 switches, the user can control the CD player's 4 functions; Play, Stop, Prev and Next.

*Adapted Music Player* can come also with a timer connected to the Play function. The timer can be directed up to 5 min. after which the CD enters in Pause mode. This feature forces the user to press again on the switch in order to continue playing the music.



### Additional details:

- This *Adapted Music Player* has a CD player, AM/FM radio and a cassette player all in one unit!
- Switches NOT included.
- Warranty: 12 month.
- Delivery cost is included.
- Money back guaranteed if returned within 14 days.
- Size: 36cm x 19cm x 27cm (14.20" x 7.50" x 10.60")